



# INSTALLATION INSTRUCTIONS ANCHOR KIT EA101 & EA102

DOC REF: 425 ISSUE 01

**Kit EA101** - Anchors, straps and fittings.

**Kit EA102** - Anchors, straps, fittings and installation tools.



1

Mark hole positions through straps, drill 2 pilot holes: 3mm dia x 45mm deep.  
Fix straps using either cross point or vandal resistant screws.  
Position seat.



**Note:**  
If removal of seat is likely use the cross point screws.

2

## ANCHORING

Insert drive bar though sleeve and into anchor. Position anchor through the strap.  
Using the hammer drive the anchor, at a shallow angle from the vertical, until flush with the strap.





3

## DRIVING OUT THE FLUKE

Remove sleeve and using the drive bar only hammer down to drive out the fluke.  
Remove drive bar and push the tube caps into the tops of the anchors.




4



5

Anchor the two diagonally opposed corners of the seat



PLAN VIEW



Earth Anchors Ltd  
15 Campbell Road, Croydon, Surrey CR0 2SQ, United Kingdom.  
Tel: 020 8684 9601 Fax: 020 8684 2230  
[www.earth-anchors.com](http://www.earth-anchors.com)

DOC REF: 425 ISSUE 01